

PS1000 Floor Scales

Features

Construction– Rugged steel with tread plate surface protects animals and handlers from accidental slips and falls. Adjustable foot pads allow scale to work effectively on uneven floors.

Overload Capacity– Capable of withstanding 150% capacity of weight without damaging the scale

Easy Assembly– No installation costs or parts that require maintenance. Just place the scale on a hard surface and level by adjusting the foot pads. Connect the indicator and turn on the power.



Shown with optional indicator stand



Shown with optional indicator stand

Specifications

Capacity– 1,000 lb x 0.5 lb (500 kg x 0.2 kg)

Power– Four (4) AAA batteries or 6 VDC, 500mA adapter, both included

Operating Temp– 41° F to 95° F (5° C to 35° C)

Battery Life– 20 hours

Display– Five 0.625" digits (17 mm) LCD

Scale Dimensions–

Scale: 55.75" L x 20.25" W x 2.5" H

Shipping Carton: 57.5" L x 22" W x 4" H

Scale Weight– 60 lb (27 kg)

Shipping Weight– 90 lb (41 kg)



Indicator– 6.5" L x 3.2" H x 1.2" W

Serial Port– One full duplex RS232, with cable

Keyboard– Hold/Print, Units, Tare, On/Off/Zero


Unit– lb, kg, lb/oz

Option– Indicator stand

Stand height: 36"; weight 11 lb

Stand base: 11.5" L x 11.5" W x .75" H

Certifications– Full FCC compliance, UL/CUL power adapter



a division of Avery Weigh-Tronix, LLC

Salter Brecknell Weighing Products

1000 Armstrong Dr., Fairmont, MN 56031
Toll free: 800-637-0529, Tel: 507-238-8702
Fax: 507-238-8271
e-mail: sales@salterbrecknell.com
www.salterbrecknell.com

